

User Instructions Pingi i-Dry XL



Thank you for purchasing this quality product from the Pingi family: the new generation of friendly dehumidifiers. We request that you review these user instructions carefully and keep them in a safe place.

Application:

The Pingi i-Dry XL moisture trap is extremely versatile, making it ideal for use as an effective moisture trap in small areas such as drawers, storage boxes, cupboards, wardrobes, bookshelves, car boots, bathrooms and on window sills - in fact anywhere a power source may not be easily accessible. Pingi i-Dry XL effectively protects your valued belongings against the harmful effect of excess moisture.

User Instructions

1. Before use, please remove the plastic foil from the product.
2. The indicator screen in the middle of the device should be bright blue. This means the entire moisture absorption capacity is available. Pingi i-Dry XL is ready for use and can be deployed. (Do not insert the plug into the power point at this time; Pingi absorbs moisture without using electricity)
3. During use, the indicator screen changes from blue to purple and finally to pink. This means that the device is completely full of moisture and needs to be recharged.
4. To recharge Pingi i-Dry XL, please connect the power plug to the back of the device and insert the plug into the power point. Recharging begins automatically when Pingi i-Dry XL is connected to the mains supply.
5. After 8 to 15 hours of recharging, the indicator screen will again turn blue. You can now remove the plug from the power point after which the Pingi i-Dry XL is again ready for use. Recharging works best in a well-ventilated area indoors and can be repeated accordingly.

Cleaning

If necessary, wipe off the exterior of the Pingi i-Dry XL with a lightly dampened cloth. During recharging, the device automatically kills the bacteria, etc. absorbed in the water.

Warnings

1. Never immerse Pingi i-Dry XL in water.
2. Do not drop or open the device.
3. Never cover Pingi i-Dry XL while recharging and avoid placing the device in direct contact with moisture-sensitive surfaces. Do not recharge Pingi i-Dry XL in small, poorly ventilated areas.
4. During recharging, Pingi i-Dry XL can feel warm or hot and water vapour will normally be released. Therefore, be careful when touching.
5. Do not allow the device to remain in the power point for more than 15 hours.
6. Please keep the device out of reach of children during recharging, as mild heat may be generated.
7. Please observe the instructions in this manual to ensure optimal product performance and durability.

Warranty

InnoGoods guarantees your Pingi product against material and fabrication faults for 5 years after initial purchase. Should material or fabrication faults be found, InnoGoods will repair or replace the device with a similar or better specified product. Damage to the device due to any form of negligence, accident, lack of cleaning and maintenance or other use that can reasonably be considered to be in conflict with the directions described in these instructions, does not fall under this warranty. Furthermore, legal provisions with respect to consumer purchases apply. In the event of a fault, we advise you to return the product together with the original proof or purchase to the store or, if this is not possible, InnoGoods B.V. When the device defect is caused by anything other than material or fabrication faults, you can be charged for examination and repair costs.

Product specifications

Product code: ID-500-EN

Batch number: -XXX-

Contact

InnoGoods B.V.

Postbus 81180

NL-3009 GD Rotterdam

The Netherlands

For service, current consumer information and tips, consult our website

www.pingi.eu